

FirePro® HES



Tools required

- Sharp knife or scissors
- Sealant gun

Fixing and application

1. Prepare joint to be sealed ensuring all surfaces are clean and sound, free from dirt, grease and any other contaminants.
2. Insert backer to the required seal depth dependent upon fire performance required.
3. Cut nozzle to the desired angle and gun firmly into the joint to give a good solid fill to the required depth.
4. Strike off the sealant flush with the joint sides within five minutes of application, before surface skinning occurs.
5. A small amount of shrinkage will occur on curing. If a flush finish is required, fill the joint slightly proud of the surface to allow for shrinkage.

Other installation information

The sealant is not intended for application on bituminous substrates or substrates that can exude certain oils and plasticizers or solvents.

The sealant is not recommended for submerged joints or areas exposed to high abrasion.

The sealant is not suitable for food contact or medical applications.

Health & safety

The mechanical effect of fibres in contact with skin may cause temporary itching.



Cover exposed skin
When working in unventilated area wear disposable face mask.



Clean area using vacuum equipment.



Waste should be disposed of according to local regulations.



Rinse in cold water before washing.



Ventilate working area if possible.



Wear goggles when working overhead.

Disclaimers

ROCKWOOL Limited, its affiliates, its agents and employees and all persons acting on its or their behalf (collectively "ROCKWOOL"), disclaim any and all liability for any errors, inaccuracies or incompleteness contained in any installation guidance or in any other disclosure relating to any product.

Usage of the information remains under the sole responsibility of the purchaser and/or user.

ROCKWOOL makes no warranty, representation or guarantee regarding the information contained in the installation guidance, the suitability of the products for any particular purposes or the continuing production of any product. To the maximum extent permitted by applicable law, ROCKWOOL disclaims (i) any and all liability arising out of the application, use of any product, misuse or inability to use the product (ii) any and all liability, including without limitation special, consequential or incidental damages, and (iii) any and all implied warranties, including warranties of fitness for particular purpose, non-infringement and merchantability.

Information contained in this document is up-to-date as at the date of issue. As ROCKWOOL Limited cannot control or anticipate the conditions under which this product may be used, each user should review the information in specific context of the planned use. To the maximum extent permitted by law, ROCKWOOL Limited will not be responsible for damages of any nature resulting from the use or reliance upon the information contained in this data sheet. No express or implied warranties are given other than those implied by law.